

Ecodeck^{tm.}



STRUCTURAL DECK TILES INSTALLATION GUIDELINES

- 1) Install and level pedestals with slope corrector or plastic shims, place each pedestal in its approximate location so that it is ready to accept a each tile. The leveling of each pedestal can be done once the tile is in place.
- 2) Place each tile over the pedestals and shim the pedestal to be level, you are looking for an even height of each corner of each tile on the pedestal. The use of rubber shims can be used to micro adjust a corner of a wood tile up if needed.



- 3) Once the tiles are laid out and leveled you can attach our wood fastening stainless washers to the deck as seen in the photo below.



- 4) Slip a 1 inch stainless screw down into the middle of the washer and spacer tab underneath.



- 5) Tighten the screw just enough to lock the tiles in place, (you will go back to each screw and do a final tightening once all the tiles are in place. You will need a

narrow head Phillips head to do this adjustment.



- 6) Once all the tiles are laid out and fastened we recommend letting the tiles weather and acclimate to the environment before applying a coat of oil penetrating sealer. We recommend the use of Cabot Australian Timber oil in the darkest tint available (Walnut or Mahogany Flame) This is the longest lasting penetration for color. We have also had very good results with Sikkens Marine Products for Teak and hardwoods. Below deck is our Ipe Structural Deck tile in mahogany flame tint.

